

## Lagondaforum: Scews missing...

### Scews missing...

*Written by H 54 John at Mar 29, 2008 7:14 pm*

Anyone know the sizes etc of the 2 screws that secure the cap on the inboard end of the steering column (i.e. the cap carrying the horn button)? Both are missing on my car and the insulating tape holding the cap in place is hardly concours...

Thanks!

John

---

### Re: Scews missing...

*Written by Brian Savill at Apr 10, 2008 9:24 pm*

Hi John.

You do not state what model. I do know that the later 2 Litre and 16/80 has 4 screws that secure the boss that the horn button fits in. They are 3/16 inch Whit. (24 TPI) 5/8 long C/SK screws.

Hope this helps.

Regards, Brian. (S28)

---

### Re: Scews missing...

*Written by H 54 John at Apr 11, 2008 11:47 am*

Thanks very much Brian. The car is a 1928 high chassis tourer. I'll try the Whitworths asap.

John

---

### Re: Scews missing...

*Written by H 54 John at May 15, 2008 7:48 pm*

Just to conclude this thread - in the early 2 litres (14/60 and HC tourer anyway), the 2 screws securing the cap are 5 BA (at least these worked for me, without obvious thread gaunching..)

John

---